

Headliner gap filler instructions

Print this template on U.S. Letter size paper.

Cut out the two shapes, and tape them together so that the dotted lines match up.

Check the template fits the available space. Trim if necessary.

Place template over 1/8" plywood. Trace or cut around the template.

Finish/cover with your choice of material.

Attach to B-pillar using stand-offs and VHB tape.

(Flip template for left hand gap)

